

## decotric Roller Adhesive for non-woven wallpapers ready-mixed

Instructions for use:

decotric Roller Adhesive for non-woven wallpapers is excellently suitable for hanging non-woven wallpapers and other form stable wallcoverings. With this technique the paste is applied onto the underground with a suitable role and the wallcovering is hung directly into the bed of paste. That way, form stable wall-coverings can simply and cleanly be hung with the modern technique of pasting the wall

- for fast and clean adhesive application, directly onto the wall using a roller
- can be used directly from the bucket
- · does not splash or drip
- with methyl cellulose
- high initial adhesion
- easy to correct
- dries to transparent finish

Technical specification:

Components: synthetic resin dispersion, methylcellulose,

starch ether, water, additives

Density: approx. 1 g/cm<sup>3</sup>

pH-value: 9.5-10.5 Usage: 200-250 ml/m<sup>2</sup>

Surface preparation:

The surface must be dry, clean, stable and free of separating agents like dust, grease etc. Prime highly absorbent, sandy or dusty surfaces with *decotric Deeply Penetrating Primer – Solvent Free*. We recommend a first coat with *decotric Wallpaper Primer white* if hanging transparent fleece wallpapers or on surfaces that are not uniform in colour.

Application:

decotric Roller Adhesive for non-woven wallpapers is ready for use and can directly be applied from the bucket onto the underground with a short-haired role. Only coat so much of the surface as can be hung with the wallcovering in approx. 10-15 minutes.

The 'open time' of 10-15 minutes refers to surface and room temperatures of +20° Celsius on moderately absorbent surfaces at 50-70 % relative atmospheric humidity.

Hang the wallpaper directly into the bed of paste and press it down evenly with a brush or a roller made of synthetic material. Hang the next strip seam-to-seam in the same way as described above. Wipe off any surplus paste at the seams with a clean, damp cloth.

Allow paste to dry completely before painting over.

High-quality non-woven wallpapers can be stripped off dryly when renovating.

Clean tools with water after use.

Do not use at surface and room temperatures of below +5° Celsius. Strictly follow the wallpaper manufacturers' hanging instructions.

Storage: Store in a cool and dry place! Store container well sealed!

**Available sizes:** 2.5 kg PE-bucket 021401001 / 4007955214014

5 kg PE-bucket 021402001 / 4007955214021 10 kg PE-bucket 021403001 / 4007955214038

decotric GmbH, Im Schedetal 1, 34346 Hann. Muenden, Germany www.decotric.com

As of: 2025-02-26