

## decotric Wallpaper Base Primer 'Tapeten-Wechselgrund' decotric Tapeten-Wechselgrund

Wall treatment for simple wallpaper removal, allowing problem-free, clean and repeated wallpaper replacement

**Instructions for use:** decotric Wallpaper Base Primer is particularly suitable for plasterboard and for

all absorbent interior surfaces, such as concrete, plaster, etc.

**Technical information:** Components: Paraffin, styrene acrylate dispersion

Density: 1.0 g/cm³ pH value: 8-9

Coverage per m<sup>2</sup>: 1 I is enough for approx. 10-20 m<sup>2</sup> (depending on

substrate)

**Surface Preparation::** The substrate must be dry, stable, and clean. Tidy up cracks and holes using

decofill Interior or decomur Super Bonding Filler. Remove old peeling paint and distempers completely using decotric Wallpaper Remover. Remove loose plaster. Strongly abrasive and chalky surfaces should be primed with decotric Deep-

ly Penetrating Primer - Solvent Free.

**Application:** Shake container before use!

Apply decotric Wallpaper Base Primer to the substrate before papering using a ceiling brush or an airless spray unit. On strongly absorbent substrates and plasterboard, use decotric Wallpaper Base Primer undiluted. On weakly absorbent substrates, dilute decotric Wallpaper Base Primer 2:1 with water.

Apply evenly.

Allow to dry for 6-12 hours depending on humidity and temperature before papering as normal, e.g. with *decotric Wallpaper Paste*. When using *KVS Cellulose Wallpaper Adhesive* for paintable wallpapers (e.g. woodchip), 20% *decotric Wallpaper and Border Adhesive* must be added to the stirred paste.

Wallpaper and Border Adhesive must be added to the stirred paste.

Do not use if the temperature of the room or substrate is below 5°C.

Clean tools with water immediately after use.

Replacing wallpaper:

Free up the upper edge of the old wallpaper using a scraper or knife and peel off in strips. Remove difficult to remove pieces of wallpaper – a result of unevenness of the substrate or possibly too thin application of Wallpaper Base Primer – using decotric Wallpaper Remover or decotric Woodchip Power Re-

mover.

**Storage:** Store in a cool and frost-free place! Keep the container tightly sealed.

Available sizes: 1.0 I PE bottle 006504001

 2.5 I plastic container
 006501001

 5.0 I plastic container
 006502001

 10 I plastic container
 006503001