

# Painter Universal Fabric

Maler- und Universalvlies 1 x 25 m

Special glass fibre fleece for surface restoration

<b>Instructions for use:</b>	Wall and ceiling surfaces riddled with hairline cracks as well as roughly structured surfaces such as removable plaster, roughcast plaster, glass-fibre fabric and the like can be renovated rationally and effectively using <i>Painter Universal Fabric</i> . The surfaces thus obtained are even and perfectly suitable for all further paint work such as painting, filling, wallpapering, plastering and gluing.						
<b>Technical data:</b>	<table border="0"> <tr> <td>Colour:</td> <td>white</td> </tr> <tr> <td>Weight per unit area:</td> <td>approx. 35 g/m<sup>2</sup></td> </tr> <tr> <td>Thickness:</td> <td>approx. 0.35 mm</td> </tr> </table>	Colour:	white	Weight per unit area:	approx. 35 g/m <sup>2</sup>	Thickness:	approx. 0.35 mm
Colour:	white						
Weight per unit area:	approx. 35 g/m <sup>2</sup>						
Thickness:	approx. 0.35 mm						
<b>Surface preparation:</b>	The surfaces must correspond to the requirements of the embedding materials to be used. The surfaces to be renovated must be dry and solid as a general rule. Prime strongly absorbent, sanding and chalking surfaces with <i>Deeply Penetrating Primer - solvent free</i> . The operating instructions of the embedding materials used must be complied with in any case.						
<b>Application:</b>	<p>For gluing <i>Painter Universal Fabric</i>, use unfilled dispersion adhesives such as <i>PUFAS Wallpaper and Border Adhesive</i> or <i>decotric Fabric Adhesive</i> or filled adhesives such as <i>decotric Styrofoam Adhesive</i> or <i>PUFAS Rigid Foam Adhesive</i> as well as <i>decomur Ready-mix Filler</i>.</p> <p>The choice of the glue depends on the surface and the work to follow. Unfilled glue can be used for renovating hairline cracks on surfaces which are already smooth. Rough, coarsely structured surfaces require the application of filled adhesives or dispersion type filling compounds.</p> <p>Apply the wall covering adhesive onto the surface using a roller or apply the filling compound with the aid of a serrated trowel, insert the <i>Painter Universal Fabric</i> in the crease-free, wet adhesive bed and press it on evenly by means of a smoothing trowel or paperhanger's spatula. <i>Painter Universal Fabric</i> can be glued in a non-overlapping (butt joint) or overlapping fashion with following overlap &amp; double cut.</p> <p>Further working on the renovated surfaces will be possible after they have completely dried.</p>						
<b>Available size:</b>	<p>Article no 009602000                  EAN 4007954096024                  Roll with 25 m x 1 m each</p>						