

decotric Wallpaper Remover

decotric Tapetenablosler

Quickly and easily removes all types of wallpapers and distemper paints.

Instructions for use: *decotric Wallpaper Remover* is suitable for easily removing paper, textile, vinyl and woodchip wallpapers as well as distemper paints.

Technical specifications:

Components:	Non-ionic tensides (surfactants)
Density:	approx. 1.0 g/cm ³
pH-value:	approx. 7
Usage:	depending on the thinning, 250 ml suffice for approx. 35-50 m ²

Application: To remove heavy wallpapers stir 250 ml *decotric Wallpaper Remover* in 10 l of water. For lightweight wallpapers the amount of water added can be increased to 15 l. Thin larger quantities with a corresponding ratio. Hot water increases the detaching effect. Apply the solution, saturating the surface, using a brush or a suitable spray gun and leave for approx. 15 minutes to take effect. If necessary apply again. The softened wallpapers can then be easily pulled off. Roughen the surface of waterproof and painted wallpapers using a needle roller or coarse abrasive paper before treating with remover.

To remove distemper paint, apply *decotric Wallpaper Remover* (dissolve 250 ml in 15 l of water) to the areas, leave to take effect for a short time and then scrape off using a stopping knife. Wash off any residues.

decotric Wallpaper Remover is neutral, stains can be easily removed with water. Subsequent pasting is not impaired.

Clean tools with water.

Important information: Please see the EU Safety Data Sheet for all safety-related data (EU-CLP).

Storage: Keep containers tightly sealed and store in a cool but frost-free place!

Available sizes:

250 ml PE bottle	005204001
1 l PE bottle	005205001
5 l PE canister	005203001