

## decotric Woodchip Power Remover decotric Rauhfaser - Kraftloeser

For the easy removal of all kind of wallpapers and stripping of old distemper.

**Instructions for use:** *decotric Woodchip Power Remover* is suitable for easily removing paper, textile, vinyl wallpapers as well as distemper paints. By the excellent stripping power it is possible to remove fast and easily even woodchip wallpapers with several coats of paint and other, similarly hard-to-strip wallcoverings.

**Technical specifications:**

Components:	ionic and non-ionic tensides
Density:	approx. 1.0 g/cm <sup>3</sup>
pH-value:	approx. 7
Consumption:	depending on the thinning, 250 ml suffice for approx. 35 - 50 m <sup>2</sup>

**Instructions for use:** Stir 250 ml *decotric Woodchip Power Remover* in 5 l of water. For lightweight wallpapers the amount of water added can be increased to 10 l. Thin larger quantities with a corresponding ratio. Hot water increases the detaching effect. Apply the solution, saturating the surface, using a brush or a suitable spray gun and leave for approx. 15 minutes to take effect. If necessary apply again. The softened wallpapers can then be easily pulled off. Roughen the surface of waterproof and painted wallpapers using a needle roller or coarse abrasive paper before treating with remover. To remove distemper paints, apply *decotric Woodchip Power Remover* (thinning 1:60) to the areas, leave to take effect for a short time and then scrape off using a stopping knife. Wash off any residues. *decotric Woodchip Power Remover* is neutral, stains can be easily removed with water. Subsequent pasting is not impaired.

Clean tools with water.

**Important information:** Please see the EU Safety Data Sheet for all safety-related data (EU-CLP).

**Storage:** Keep containers tightly sealed and store in a cool place!

**Available sizes:**

250 ml PE bottle	006704001
1 l PE bottle	006705001