

decofill Woodchip Repair Filler

decofill Rauhfaser Reparatur

Ready-to-use synthetic resin filling compound with woodchip structure

Instructions for use: *decofill Woodchip Repair Filler* is perfectly suitable for mending damaged woodchip wallpapers. Ideal for repairing dowel holes, cracks and similar damaged areas. Thanks to its structure, the filler adapts itself perfectly to the woodchip granulation.

Not suitable for filling work on wood, metal, glass and plastic.

Technical data:

Components:	Styrene-acrylate dispersion, filling material, additives, wood fibre
Density:	approx. 1.7 g/cm ³
pH value:	8-9
Drying period:	approx. 1 hour depending on coating thickness, surface absorbing capacity and ambient temperature
GISBAU product code:	M-DF01

Surface preparation: The surface must be dry, stable and free from parting compounds (grease, dust, formwork release oil, etc.). Pre-fill holes and cavities with *decofill Interior* or *decomur Super Bonding Filler*. Pretreat strongly absorbent, sanding or chalking surfaces with *decotric Deeply Penetrating Primer – Solvent Free*. Glue open seams of the woodchip wallpapers with *decotric Seam Adhesive*.

Application: Knead tube well before each use. Apply *decofill Woodchip Repair Filler* directly from the tube onto the damaged area using a spatula and create the desired surface structure using a spatula or brush. The filled surface can be painted over after complete through drying.

Do not process below +5° Celsius sub-floor and room temperature!
Clean tools with water immediately after use.

Storage: Store in a cool, but frost-free place. Keep the containers tightly sealed!

Available size: 330 g PE tube 034201001