

decotric Wood Putty

decotric Holzkitt

Ready to use, natural coloured synthetic resin filler for the fast repair of wooden surfaces

Instructions for use: *decotric Wood Putty* is suited for filling and smoothing cracks and holes as well as cracked edges on wooden surfaces. Usable for indoors and - with a weatherproof additional paint - also for outdoors.

Technical specifications:

Components:	Styrene acrylate emulsion, fillers, additives
Colour:	beige
Density:	approx. 1.80 g/cm ³
pH-value:	approx. 8-9
Drying time:	6-12 hours, depending on the thickness of the layer, absorbency of the surface and ambient temperature
Usage:	approx. 1.8 kg/m ² for 1 mm thick filler layer

Surface preparation: The surface must be dry, firm and free of release agents. Remove weathered wood up to the healthy layer.

Application: Knead the tube well before use. Use a smoothing trowel to apply *decotric Wood Putty* with a layer up to max. 5 mm thick. Unevenness can be smoothed or felted over when moist. After the filled area has completely dried, *decotric Wood Putty* can be coated over with all water based colours and lacquers.

When using *decotric Wood Putty* outdoors, apply a weather-proof additional paint after moist.

Do not use on surfaces or in rooms below + 5° Celsius!
Clean tools with water immediately after use.

Storage: Store in a cool, but frost-free place. Keep the containers tightly sealed!

Available size: 400 g PE tube 008202001