

aka TAB Wallpaper & Woodchip Rapid-Action Remover aka TAB

Ready to use, solvent-containing siloxane façade impregnation

Instructions for use: aka TAB Wallpaper & Woodchip Rapid-Action Remover removes all standard

paper, vinyl and embossed wallpapers as well as distempers and washable paints quickly, cleanly and safely. The product's particularly powerful removal properties allow even multi-knitted woodchip wallpapers and similar difficult to

remove wallpapers to be removed quickly and easily.

Technical information: Components: non-ionic tensides, water, additives

Density: 1.0 g/cm³ pH value: approx 7-8

Coverage per m²: depending on dilution,

100 ml is enough for approx. 50-100 m²

Application: For light wallpapers and washable paints, stir 125 ml of aka TAB Wallpaper &

Woodchip Rapid-Action Remover into 20 I of water. For heavy and washable

wallpapers, 250 ml in 10 l of water.

Apply the solution evenly and generously using a ceiling brush. Depending on wallpaper type, allow 2-20 minutes to take effect. To prevent the solution from drying onto the wallpaper, keep windows closed. Free up the edge of a sheet at the top or bottom using a scraper and peel wallpaper away from the wall slowly. For heavy and washable wallpapers a second or third application may be nec-

essary.

For special wallpapers, such as plastic-coated or 100 % washable papers, it may be necessary to roughen the surface using a wallpaper perforator, steel brush or rough sandpaper. To remove distempers, apply the solution generously. Scrape the paint off with a scraper, then wash the surface with water.

Clean tools with water immediately after use.

Important information: Please see the EU Safety Data Sheet for all safety -related data (EU-CLP)

After contact with skin, wash immediately with plenty of water.

Storage: In a cool place, protect from frost! Ensure that the container is properly closed

during storage!

Available sizes: 070101000 4007954701010 250 ml

070104000 4007954701041 1