

decotric Assembly Adhesive

decotric Montage- und Universalkleber

Solvent-free emulsion adhesive for fast and reliable gluing of interior wall and floor coverings.

Instructions for use:

decotric Assembly Adhesive is ideally suitable for gluing foam and jute-backed carpets, PVC floorings with felt and non-bonded backings, PVC wallpapers and wall tiles, ceramic tiles, Styropor[®], wall cork, wood, PU foam beams, wood and wall panels, insulating wallpapers (Sempatap, etc.), glass mosaics, decorative strips made from polystyrene, décor and insulating panels, baseboards, etc. Not suitable for gluing polyethylene, polypropylene and metallic materials. (Styropor[®] is a registered trademark of BASF AG)

Technical specifications:

Components:	copolymer plastic emulsion
Density:	approx. 1.4 g/cm ³
pH-value:	7-8
Usage:	approx. 300-700 g/m ² , depending on the surface property and stopper knife indentations
GISBAU GISCODE:	D 1

Surface preparation::

The surface must be dry, firm and free of release agents (grease, dust, etc.) Remove loose plaster. Remove old wallpaper and flaking paint using *decotric Wallpaper Remover* Make good cracks and holes in ceilings and walls using *decomur Super Bonding Filler* or *decofill Interior*. Level out uneven floors using *AKAPLAN Floor Smoothing Compound* or *AKAFLEX Wood Flooring Smoothing Compound*. Always pretreat highly absorbent, sanding and chalking surfaces using *decotric Deeply Penetrating Primer – Solvent Free*.

If the material to be glued cannot absorb moisture, the surface must be absorbent.

Application:

Apply *decotric Assembly Adhesive* evenly to the surface using a spreading comb. Use a spreading comb with A2 indentations for PVC coverings and foam-backed carpets. We recommend B2 indentations for coverings with a rough underside (e.g. jute-backed carpets) as well as for tiles. Place flexible coverings (PVC wallpapers, etc.) in the still moist adhesive bed and press with a rubber roller. Press rigid coverings (tiles, etc.) using a sliding movement.

Roll out carpeting and PVC coverings one day before laying due to the formation of creases. Observe the covering manufacturer's laying instructions.

After the adhesive has completely dried the covering can be jointed or its seams welded. The drying time is approx. 1-3 days depending on the ambient temperature and the absorbency of the surface.

Remove residual adhesive immediately with water. Do not use if the surface and/or room temperature are below + 5° Celsius! Clean tools in water immediately after use.

Storage:

Store in a cool place! Keep containers tightly sealed!

Available size:

750 g PE	001601000
----------	-----------